

orders@inkjetbiz.com (408) 394 -7595

# XPress 11 Oz Single Mug USER MANUAL



#### NOTICE

- 1. Use the heat transfer press only as intend
- 2. Please keep children away from the machine
- 3. Use correct power outlet before plugging in the device
- 4. Burns can occur from contact with hot surface
- 5. Please hold the handle firmly when machine is opening
- 6. Turn off the device when not in use and remove the power plug






### 

• In the Box	03
Product Features	04
Display Settings	05/06
Transfer Parameters	07
• Troubleshooting	08

#### **XPress 11 Oz Single Mug Press (110v)**

#### MACHINE INTRODUCTION





1. Timer Start

2. Heater

3. Heater Connector

4. Power Cable Connection

5. Power Switch

6. Control Display

7. Handle Grip

8. Handle Bar

9. Pressure Knob

#### CONTROLLER PROGRAM

#### CONTROL SETTING













: Timing in Seconds









Plus Digits









Control Panel Display



P-3:°C or °F Read-out Touch SET & ↑↓ buttons to set °C or °F



Auto-off Introduction It reads OFF and machine starts to cool down after machine raises to SET temp, and remains no operation for P-4 set time. Operation like control panel setting or heat pressing.



P-1: Temp. Setting Mode Touch SET & ↑ ↓ buttons to set desired Temp.



P-3:°C or °F Read-out Touch SET & ↑ ↓ buttons to set °C or °F



Wake Machine from Sleepy Mode You can wake up the heat press from sleepy mode by touching any button on the control panel, and machine starts to heat again.



P-2: Time Setting Mode Touch SET & ↑ ↓ buttons to set desired time.



P-4: Auto Power-off Mode Touch SET & ↑ ↓ buttons to set auto-off time with 0-120 mins range



Clear Counter NO. You can long hold the CLEAR button to clear the COUNTER NO. on the panel.

#### Transfer Parameters

TRANSFERS	PRINTHEAD	MARK	TEMP.	TIME	PRESSURE
SubliMate Paper	TFP, DX	Coated Mug	400°F	180 sec.	High
Shock Line Paper	Toner	Coated Mug	356°F	180 sec.	Medium to High

## For any further help, please contact our support team.

support@inkjetbiz.com (408) 394-7595

#### Troubleshooting

- Q:When image is pressed, the color of the design is faded or transfers are not fully transferred onto the mug.
- A: Reason comes from three points, there is little to no pressure, the temperature is not hot enough, or it is pressed for too little time. Test different points to get a better transfer.
- Q:After transferring my image has shifted or "ghosted".
- A: During the pressing process, the image may have shifted positions on the mug causing ink to continue imprinting but in a different spot. We recommend to use heat tape to secure the image on your substrate so that it doesn't shift at any point.
- **Q**: How to get a reasonable pressure.
- A: Adjust the pressure by turning the knob and lock down the handle. There should be a larger resistant force soon after.
- I Q: Turn on the power, but the mug press machine does not work.
- A: Please check the power plug to see if it is well connected to the socket; if problem persists, turn to our support team for help.
- I Q: Pressure knob is too hard to adjust.
- A: Adding lubricant oil to make the joint smooth.
- **I** Q: The temperature remains unchanged in P-1 and cannot go up anymore
- A: Press Timer Start button to restart machine. If problem persists, turn to our support team for help.
- I Q: The mug press machine has peculiar smell during operation.
- A: It is normal when you heat the silicone material on the heater element.
- Q: I want to apply my image on different mug sizes.
- A: You can order additional heating elements for 12 oz, 15 oz and 17 oz. Contact orders@inkjetbiz.com or visit www.inkjetbiz.com