

GO Xpress C-1200/C-1700 Control Panel

Celendar Control Panel Settings

This bulletin describes the Control Panel Settings on the C-1200 and C-1700 Calendar units.



Powe On/Off: Press the Button to Turn On or Off the Unit.



Direction Switch: Control the Rotation Direction of the Cylinder



Motor On/Off: Start or Stop the Motor



Heating: Start or Stop the Heating Function

To set up the Temperature, use the Up and Down Arrows. The Actual Temperature Will be Displayed After 6 Seconds Setting.

Specification Settings:

Press and hold for three  (3) seconds to enter in the configuration mode.

Press  to change between D-1, D-2, D-3, D-4, D5 in order.

END to confirm the selected value. Use the Up and Down keys to change the values.

If any button is not pressed during the setting for one (1) minute, the specifications settings will end automatically.



Spec No.	Content	Temp. Range	Default
D-1	Temp. Calibration	-50---50	0 °C
D-2	High Temp. Alarm Point	10 - 270 °C	250 °C
D-3	Max Temp.	10 - 250 °C	220 °C
D-4	Temp Unit	0 = °C 1= °F	°C
END			