


# GO Xpress Xpress 912CS

## 9120CS Clamshell Recommendation

Due to the size of the platen and the heat press being closed during transportation, the base rubber might be stuck to the heating platen.

When unboxing the Xpress 912CS, follow this procedure to prevent the base rubber from being attached to the heating plate, causing issues when turning the unit on.

1. Once unboxed, the Xpress 9120 will be closed. Open it gently and peel the lower platen rubber that will be attached to the top heating platen.



2. When the rubber is removed, place it on the bottom plate. And the machine can be turned on to heat the platen.

A Lower Platen Heat Press Protector is perfect to protect the rubber from the heat.

